





Green Infrastructure Grant for the Combined Sewer Area Program Operation & Maintenance Workshop Session

Reducing rain and stormwater from our combined sewer system



#### Agenda

- Introduction
- O & M General Overview (Design, Construct, Maintain)
- Stormwater Control Measures
- Annual Inspections
- Educational Signage
- Grant Reporting Tool



#### Introduction

The Northeast Ohio Regional Sewer District supports the strategic implementation and long-term maintenance of green infrastructure that protects, preserves, enhances, and restores natural hydrologic function.

#### Introduction

Requiring all grantees to attend an Operation & Maintenance (O&M) Workshop to ensure that green infrastructure practices through our GI Grant Program Agreement, will continue to function properly and yield expected water quality and environmental benefits, while ensuring good stewardship of rate payer dollars.

#### Green Infrastructure Grant

Funding Round	Award Recommendations Total	Runoff Reduction gallons/year Total
2014 – 2023 GIG PROGRAM	\$12,728,824	35,066,342
2024 GIG PROGRAM	1,625,000	2,904,305
GRAND TOTAL	\$14,353,824	38,266,308



## Operation & Maintenance General Overview

Operation & Maintenance Workshop Session

## Design

### Construct

## Maintain





















# General Overview Design Considerations

How to minimize maintenance and simplify inspection

- Begin with the end in mind
- Setup project for success
  - Construction
  - Long-term maintenance



Refer to an accepted standard



## Rainwater and Land Development

Ohio's Standards for Stormwater Management Land Development and Urban Stream Protection

\*Third Edition 2006

\*Updated to include all new materials, changes and corrections as of 11-6-14.

Ohio Department of Natural Resources Division of Soil and Water Conservation

2045 Morse Road, Building B-3 Columbus, Ohio 43229-6605 (614) 265-6610

#### Ensure accessibility by needed equipment



**EASY ACCESS** 




**DIFFICULT ACCESS** 


#### Schedule

1. Timing of Construction - Construction of bioretention practices shall take place after land grading is complete and the contributing drainage area has been stabilized. Construction may take place if the entire contributing area can be effective diverted until construction is complete and fully-vegetated cover protects all soil Construction shall not occur during periods of precipitation since clogging of soil ding, filter or planting media may occur.





Consider ways to simplify inspections (e.g., observation wells)







Flood Routing
What happens if the practice clogs/fails?








#### Materials Specifications


- 4. *Planting Soil* The planting soil filters the treatment volume, detains runoff in the available void space and provides a media for plant growth and a biological community. Much of the pollutant removal occurs in this zone due to filtering, microbial activity, ion exchange, adsorption and plant uptake. The planting soil (an engineered soil media) shall be at least two feet deep and up to four feet in depth (settled) depending upon the planned vegetation. Greater depth is necessary to accommodate the root ball of trees planted in bioretention facilities. Soils and soil mixes must be certified by a qualified laboratory (1 test per 100 yd<sup>3</sup> of soil) and have the following attributes:
  - Texture class: loamy sand. Having no less than 80% sand and no greater than 10% clay considering only the mineral fraction of the soil.
  - pH range: 5.2 8.0
  - Soluble Salts: 500 ppm maximum.
  - Decomposed organic matter: 3-5% by weight [Note: this translates to 8-20% organic matter by volume. See note on "Creating a Suitable Soil Media" below.]
  - Phosphorus: phosphorus of the planting media should fall between 15 and 60 mg/kg (ppm) as determined by the Mehlich III test. For sites in watersheds with a phosphorus TMDL or sites with high phosphorus loads, the phosphorus content of the planting media should fall between 10 and 30 mg/kg as determined by the Mehlich III test.
  - Sand added shall be clean and meet AASHTO M-6 or ASTM C-33 with a grain size of 0.02-0.04" inches.



#### Applicable Notes & Details



#### Applicable Notes & Details



Sub-grade infiltration testing for assumed locations & approximate depths of SCMs






#### Proximity of SCMs to Foundations





Horizontal Separation Distances

• separation from buildings - pervious pavement systems should be installed at least 10' away from up-gradient building foundations and 100' from down-gradient foundations, unless an acceptable barrier is provided or the building foundation can adequately handle additional water;



## General Overview Construction Considerations

How to achieve your SCM's intended function (a.k.a., how to not mess it up)



#### Do not ruin your SCM!





#### Follow the construction schedule (the recipe)

- START-UP SEQUENCE:
- INSTALL TEMPORARY EROSION AND SEDIMENT CONTROL (SILT FENCE, CONSTRUCTION ENTRANCE, CONCRETE WASHOUT ETC...) INLET PROTECTION ON ALL PERMANENT STORM SEWER INLETS, STRUCTURES AND STRUCTURES TO REMAIN THROUGH CONSTRUCTION
- CONTRACTOR SHALL DEFINE STAGING AREA LIMITS
- INSTALL SAFETY SIGNAGE, HEALTH AND SAFETY PROCEDURES
- MARK STOCKPILE AREAS, CONSTRUCTION ENTRANCES AND LOADING/UNLOADING AREAS
- CONSTRUCTION SEQUENCE:
- INSTALL PERIMETER TEMPORARY EROSION AND SEDIMENT CONTROL PRACTICES PER PLAN AND DIRECTION
- DEMOLITION AND CLEAR CONSTRUCTION AREA PER THESE PLANS
- FINAL GRADE WITH STONE PARKING LOT PER GRADING PLAN AND STABILIZE AREAS DRAINING TO BIORETENTION AREA
- TEMPORARY SEED AND MULCH DISTURBED AREAS AS REQUIRED
- INSTALL BIORETENTION AREA AS PER PLAN
- FINAL SEQUENCE
- FINALIZE ALL CONSTRUCTION ACTIVITIES, INCLUDING PAVING
- PERMANENT SEED & LANDSCAPE AREAS AS NECESSARY
- REMOVE ANY REMAINING TEMPORARY SEDIMENT CONTROL DEVICES AS REQUIRED
- CLOSE OUT PROJECT



#### Scarify underlying subsoil of infiltrating practices






Keep sediment out!!








#### Refer to applicable notes




#### UTILITY NOTES:

- PRIOR TO CONSTRUCTION THE CONTRACTOR SHALL LOCATE EXISTING SLANTS #21 AND #28 FOR RE-USE. CONTRACTOR SHALL EXPOSE SLANT AND IT SHALL BE INSPECTED BY WATER POLLUTION CONTROL FOR REUSE. IF CONNECTION IS VIABLE CONTRACTOR SHALL NOTIFY ENGINEER OF LOCATION AND ELEVATION. IF WATER POLLUTION CONTROL DETERMINES THE SLANT IS NO LONGER VIABLE THE CONTRACTOR SHALL INSTALL A NEW 6" VCP SLANT PER WPC STANDARDS. CONTRACTOR TO COORDINATE WITH WATER POLLUTION CONTROL. SEWER WITHIN THE R/W, FROM TEST TEE TO THE MAIN SHALL BE 6" VCP @ A MINIMUM SLOPE OF 1.0%.
- PROPOSED GAS METER. LOCATION AND SIZE AND CONNECTION TO BE COORDINATED WITH UTILITY COMPANIES PRIOR TO CONSTRUCTION.
- RELOCATED WATER SPIGOT. CONTRACTOR TO COORDINATE FINAL LOCATION WITH OWNER PRIOR TO CONSTRUCTION. IF EXISTING SHUT OFF VALVE IS WITHIN CONSTRUCTION LIMITS, CONTRACTOR SHALL ALSO RELOCATE VALVE WITH WATER SPIGOT.
- PROPOSED ELECTRIC METER AND TRANSFORMER. CONTRACTOR SHALL COORDINATE WITH MEP PLANS AND UTILITY COMPANIES PRIOR TO CONSTRUCTION.
- 5 PROPOSED 4" FIRE LINE AND 2" DOMESTIC LINE. METER AND BACKFLOW SHALL BE LOCATED INSIDE BUILDING.
- (6) CURB UNDERDRAIN. SEE DETAIL SHEET C6.01.
- 6" PERFORATED UNDERDRAIN AT 0.3% SLOPE WHERE PAVERS MEET BUILDING.
- (8) SOLID PIPE FOR CONNECTION BETWEEN PERFORATED PIPE AND COLLECTOR PIPE.

#### Complete as-built drawings





Update O&M plan as applicable when design changes are made during construction

Sub-grade infiltration testing for exact locations & excavated depths of SCMs





NOTE: Unexpected infiltration rates can trigger design revisions.

Construct infiltrating practices during dry weather only






## Ensure non-contaminated construction materials are used





#### Ensure planting specifications are followed







## General Overview Maintenance Considerations

Inspection: knowing what to look for and knowing how to remedy problems

### General Overview - Day 1





### General Overview - Day 1




### General Overview - the first few months





## General Overview – the awkward years





## General Overview - Maturity







# What do the following have in common?



A man-made feature that requires no maintenance










A prefect system of government

## THEY DON'T EXIST!!!

First year need \$ vs long-term need \$







MAINTAINING STORMWATER CONTROL MEASURES
Guidance for Private Owners & Operators

STORMWATER CONTROL MEASURES

#### Stormwater Control Measures

Over the next few pages we will discuss common SCMs approved for use in Ohio. A good understanding of SCM design and operation will enable property owners and operators of SCMs to plan and implement required maintenance activities on schedule.

If your SCM is not listed in this manual, please contact your local stormwater manager.

- Bioretention Area (page 7)
- . Dry Pond or Dry Extended Detention Basin (page 9)
- Wet Pond or Wet Extended Detention Basin (page 11)
- · Vegetated Infiltration Swale (page 13)
- Permeable Pavement (page 15)
- Green Roof (page 18)
- Non-Structural SCMs: Riparian & Wetland Setbacks and Conservation Areas (page 19)
- Rain Barrels & Cisterns (page 21)
- Rain Gardens (page 23)
- · Sand Filter System (page 25)
- Underground Detention (page 27)
- Oil-Water Separator (page 29)

#### MAINTAINING STORMWATER CONTROL MEASURES Guidance for Private Owners & Operators

#### TABLE OF CONTENTS

2	History of Starmounter Management Solutions in Ohio
2	History of Stormwater Management Solutions in Ohio
4	Key Points to Remember When Using This Guidance Manual
6	Stormwater Control Measures
30	Routine and Non-Routine Maintenance
42	Inspection & Maintenance Agreements and Easements
43	Tips to Lessen Maintenance Costs
APPENDIX 1	Glossary of Commonly Used Terms
APPENDIX 2	Inspection & Maintenance Check Lists
APPENDIX 3	Operation & Maintenance Resources
APPENDIX 4	Inspection & Maintenance Agreement Template
APPENDIX 5	Bioretention Area & Rain Garden Planting Lists
APPENDIX 6	List of Common Invasive Plants


https://neohiostormwater.com/uploads/3/5/0/4/35043674/maintaining\_scm\_manual\_final.pdf

#### MAINTAINING STORMWATER CONTROL MEASURES Guidance for Private Owners & Operators

#### STORMWATER CONTROL MEASURES

#### **Bioretention Area**

Bioretention areas are depressed areas that allow shallow ponding of stormwater runoff that utilize specified soil media, mulch and vegetation to capture and treat stormwater runoff from impervious surfaces such as parking lots and rooftops. The soil media, mulch and vegetation filter pollutants to improve water quality within urban environments. The specified soil media, composed of sand, is placed over layers of sand, pea gravel and gravel within the depression which enables ponded stormwater runoff to be treated and filtered and before either soaking into the underlying soils or leaving through an underdrain pipe. Underdrains may be installed to drain the bioretention area to local sewers or appropriate outlet. Bioretention areas are planted with specific types of plant material that can withstand both wet and dry weather conditions. Recommended plant material information for Bioretention Areas can be found in Appendix 5.



Typical bioretention area cross-section view. Credit: Chagrin River Watershed Partners, Inc.

#### MAINTAINING STORMWATER CONTROL MEASURES Guidance for Private Owners & Operators

#### STORMWATER CONTROL MEASURES



Planted bioretention area with sidewalk curb cut in foreground. Stormwater runoff is conveyed through gravel to shallow depression of bioretention area. Credit: Northeast Ohio Regional Sewer District



Weeds and untrimmed plantings prevent stormwater runoff from entering the bioretention area from the curb cut. Credit: Northeast Ohio Regional Sewer District



Stormwater flow will be blocked by the dead vegetation on the outlet catch basin grate. Credit: Chaarin River Watershed Partners



Erosion of side slopes and subsequent sediment accumulation within bioretention area and contribute to clogging issues. Credit: Summit Soil & Water Conservation District

#### MAINTENANCE REQUIRED WHEN:

- Standing water is visible 48 hours after a rain event.
- Erosion is visible within the bioretention area, or on the slopes and inlets leading into the bioretention area.
- · Vegetation, sediment or debris is blocking inlets or outlets.
- · Vegetation is wilting, discolored, or dying.
- · Foul odors present.
- · Sediment has accumulated over the mulch or soil media

https://neohiostormwater.com/uploads/3/5/0/4/35043674/maintaining\_scm\_manual\_final.pdf

#### MAINTAINING STORMWATER CONTROL MEASURES Guidance for Private Owners & Operators

#### ROUTINE AND NON-ROUTINE MAINTENANCE

#### Recommendations for Routine and Non-Routine Maintenance

The following section lists general recommendations for routine and non-routine maintenance items. Some routine maintenance items are completed on a seasonal basis, others require greater frequency. Non-routine maintenance items often require professional expertise and assistance before appropriate corrective measures can be determined. Resources for professional assistance are listed in Appendix 3.

#### Bioretention Area

#### Routine Maintenance:

- <u>Sediment and Debris:</u> Remove gross accumulated sediment and debris from the mulch or grass surface area of the bioretention area.
- <u>Outlet Structure:</u> Keep outlets of bioretention area free from blockage by sediment, debris, trash, mulch or plant material.
- <u>Erosion and Scour:</u> Repair soil erosion or scouring within the bioretention area, side slopes or inlets leading into the bioretention area.
- <u>Mulch:</u> Maintain a 2 to 3 inch depth of hardwood bark mulch layer within the planted area of the bioretention area. If an excessive depth of mulch exists, remove mulch until the mulch layer is 2 to 3 inches in depth.
- <u>Curb Cuts</u>: Keep curb cuts to bioretention area free from blockage by sediment, debris
  and trash.
- . Weeds: Remove weeds and invasive plants from bioretention area.
- <u>Vegetation Management:</u> Inspect plant health seasonally to ensure vigorous growth.
   Prune plants, particularly shrubs and trees, during the dormant season (fall to early spring).
- Snow Removal: Do not pile or store snow within the bioretention area as this will
  compact the specialized soils and add sediments that may lead to clogging.

#### Non-Routine Maintenance:

- Plant Replacement: Replace diseased or dying plants.
- Water Ponding Period: When ponding continues beyond a 48 hour period or the designed ponding duration, there may be construction, or design issues that need to

#### Bioretention Area Inspection and Maintenance Checklist

Facility:					
Location/Addr	Location/Address:				
Date:	Time:	Weather Conditions:		Date of Last Inspection:	
Inspector:					
	Rain in Last 48 Hours   Yes   No   If yes, list amount and timing:				
Pretreatment:   vegetated filter strip   swale   turf grass   forebay   other, specify:   ne				□ none	
Site Plan or As	Site Plan or As-Built Plan Available:   Yes   No				

Inspection Item		Comment	Action Needed
1. PRETREATMENT			
Sediment has accumulated.	□Yes □No □N/A		□Yes □N
Trash and debris have accumulated.	□Yes □No □N/A		□Yes □N
2. DEWATERING			
Standing water is present after 24 hours. If yes, describe sheen, color, or smell.	□Yes □No □N/A		□Yes □N
3. INLETS			
Inlets are in poor structural condition.	□Yes □No □N/A		□Yes □N
Sediment has accumulated and/or is blocking the inlets.	□Yes □No □N/A		□Yes □N
Erosion is occurring around the inlets.	□Yes □No □N/A		□Yes □N
3. VEGETATION			•
Vegetation is wilting, discolored, or dying due to disease or stress.	□Yes □No □N/A		□Yes □1
Vegetation needs to be controlled through mowing or manual removal.	□Yes □No □N/A		□Yes □1
4. BIORETENTION MAIN INFILTRA	TION AREA		
Trash and debris have accumulated.	□Yes □No □N/A		□Yes □!
Sediment has accumulated at the surface.	□Yes □No □N/A		□Yes □1
Topmost layer is caked or crusted over with sediment.	□Yes □No □N/A		□Yes □!
Erosion is evident.	□Yes □No □N/A		□Yes □1
Mulch is compacted.	□Yes □No □N/A		□Yes □!
Sinkholes or animal borrows are present.	□Yes □No □N/A		□Yes □!
5. SIDE SLOPES AND EMBANKMEN	T		
Erosion is evident.	□Yes □No □N/A		□Yes □1
Sinkholes or instability is evident.	□Yes □No □N/A		□Yes □1
6. OUTLETS AND OVERFLOW STRU	CTURE (i.e., catch basin)		
Outlets or overflow structures in poor structural condition.	□Yes □No □N/A		□Yes □1
Sediment, trash or debris is blocking the outlets or overflow structure.	□Yes □No □N/A		□Yes □1
Erosion is occurring around the outlets or overflow structure.	□Yes □No □N/A		□Yes □1
Height from surface of practice to top of overflow structure is insufficient to allow for ponding during rain events.	□Yes □No □N/A		□Yes □?

### 2024 Stormwater Control Measures

- Bioretention Practices
  - Bioretention cells
  - > Bioretention planters
  - > Tree vaults
- Permeable Pavement



## BIORETENTION

Operation & Maintenance Workshop Session



### Bioretention

- Small-scale, vegetated depressions
- Small contributing areas (e.g., roads and roof tops)
- Stormwater runoff percolates through soil and plant roots
- Physical, chemical and biological processes
- Clean water infiltrates or is discharged



# Overflow system Ponding area Filter Media Transition Layer Drainage Layer

## Bioretention Design

Operation & Maintenance Workshop Session

inage Pipe



### General

- Use accepted standards
- Ensure accessibility
- Prepare logical schedule
- Keep inspection & maintenance in mind
- Include applicable notes & details
- Provide for flood routing
- Provide material specifications

### Design assumptions made

- Appropriate drainage area vs. filter bed area (5% of watershed's IA)
- Adequate outlet
- Groundwater considerations
- Setbacks met

### **Assumptions**

Appropriate drainage area vs. filter bed area (5% of watershed's impervious area)



Pre-treatment options









Curb cuts: Sumps (easy) vs. Slopes (hard)





Curb cuts: Use the right size stone










### Upturned elbows





### Infiltration Testing





### Mulch Selection







### Planting Soil Media

- Texture class: loamy sand. Having no less than 80% sand and no greater than 10% clay considering only the mineral fraction of the soil.
- pH range: 5.2 8.0
- Soluble Salts: 500 ppm maximum.
- Decomposed organic matter: 3-5% by weight [Note: this translates to 8-20% organic matter by volume. See note on "Creating a Suitable Soil Media" below.]
- Phosphorus: phosphorus of the planting media should fall between 15 and 60 mg/kg (ppm) as determined by the Mehlich III test. For sites in watersheds with a phosphorus TMDL or sites with high phosphorus loads, the phosphorus content of the planting media should fall between 10 and 30 mg/kg as determined by the Mehlich III test.
- Sand added shall be clean and meet AASHTO M-6 or ASTM C-33 with a grain size of 0.02-0.04" inches.

### **Plant Selection**

- Aesthetics
- Line of site
- Moisture variability
- Salt tolerance
- Sunlight needs
- Ease of maintenance (species familiarity)



# Bioretention THE CLEVELAND MUSEUM OF Construction

Operation & Maintenance Workshop Session

#### General

- Adhere to construction schedule
- Keep sediment away!
- Refer to applicable notes/details
- Construct during good weather
- Scarify subsoil (infiltrating practices)
- Use non-contaminated materials
- Plan revisions = O&M Plan revisions
- As-built drawings
- Milestone inspections

### Avoid compaction





Account for settling of layers (additional 5% volume)







### Keep sediment out!!!







Pre-treatment grass filter strips...choose sod rather than seed & mulch






### Properly stake taller plants








## Bioretention Maintenance

Operation & Maintenance Workshop Session

### Bioretention- Maintenance

### General

- All SCMs will require maintenance
- First year need \$ vs.
   long-term need \$



#### Bioretention Area Inspection and Maintenance Checklist

Facility:					
Location/Address	:				
Date:	Time:	Weather Conditions:		Date of Last Inspection:	
	Inspector: Title:				
Rain in Last 48 Hours   Yes   No   If yes, list amount and timing:					
Pretreatment:   vegetated filter strip   swale   turf grass   forebay   other, specify:   ne				□ none	
Site Plan or As-Built Plan Available:   Yes  No					

Inspection Item		Comment	Action Needed
1. PRETREATMENT			
Sediment has accumulated.	□Yes □No □N/A		□Yes □No
Trash and debris have accumulated.	□Yes □No □N/A		□Yes □No
2. DEWATERING			
Standing water is present after 24 hours. If yes, describe sheen, color, or smell.	□Yes □No □N/A		□Yes □No
3. INLETS			
Inlets are in poor structural condition.	□Yes □No □N/A		□Yes □No
Sediment has accumulated and/or is blocking the inlets.	□Yes □No □N/A		□Yes □No
Erosion is occurring around the inlets.	□Yes □No □N/A		□Yes □No
3. VEGETATION			
Vegetation is wilting, discolored, or dying due to disease or stress.	□Yes □No □N/A		□Yes □No
Vegetation needs to be controlled through mowing or manual removal.	□Yes □No □N/A		□Yes □No
4. BIORETENTION MAIN INFILTRA	TION AREA		
Trash and debris have accumulated.	□Yes □No □N/A		□Yes □No
Sediment has accumulated at the surface.	□Yes □No □N/A		□Yes □No
Topmost layer is caked or crusted over with sediment.	□Yes □No □N/A		□Yes □No
Erosion is evident.	□Yes □No □N/A		□Yes □No
Mulch is compacted.	□Yes □No □N/A		□Yes □No
Sinkholes or animal borrows are present.	□Yes □No □N/A		□Yes □No
5. SIDE SLOPES AND EMBANKMEN	Γ		•
Erosion is evident.	□Yes □No □N/A		□Yes □No
Sinkholes or instability is evident.	□Yes □No □N/A		□Yes □No
6. OUTLETS AND OVERFLOW STRU	CTURE (i.e., catch basin)		
Outlets or overflow structures in poor structural condition.	□Yes □No □N/A		□Yes □No
Sediment, trash or debris is blocking the outlets or overflow structure.	□Yes □No □N/A		□Yes □No
Erosion is occurring around the outlets or overflow structure.	□Yes □No □N/A		□Yes □No
Height from surface of practice to top of overflow structure is insufficient to allow for ponding during rain events.	□Yes □No □N/A		□Yes □No

Additional Notes		 	
Wet weather inspection needed	□ Yes □ No		

Site Sketch:

#### Pre-treatment

Remove accumulated sediments



#### De-watering

Ensure it drains



#### Inlets

Are they stabilized?



#### Vegetative Health

Watering & weeding

Trimming/pruning

**Thinning** 

Winterizing





#### Infiltration bed











#### Outlet & Overflow






#### **First-Year Maintenance**

- Remove accumulated sediments/debris from pretreatment devices
- Stabilize eroding inlets & side slopes
- Vegetation watering, mulching & winterization
- Remove trash & debris from bed
- Address any animal burrows
- Ensure overflow remains free-flowing

#### Time for a 10-minute break





# PERMEABLE PAVEMENT

Operation & Maintenance Workshop Session

#### Permeable Pavement

- Provide structural support for vehicle, bicycle, and pedestrian traffic
- Allows water to permeate through the pavement surface, aggregate base, and to infiltrate into the subgrade soils
- Receive runoff from adjacent rooftops and/or traditional paved areas

#### Permeable Pavement

#### PERMEABLE PAVERS

#### **NON-PERMEABLE PAVERS**



VS.



DESIGNED WITH SPECIAL SPACER BARS, RESULTING IN WIDER JOINTS



Operation & Maintenance Workshop Session

#### General

- Use accepted standards
- Ensure accessibility
- Prepare logical schedule
- Keep inspection & maintenance in mind
- Include applicable notes & details
- Provide for flood routing
- Provide material specifications

#### Design assumptions made

- Traffic loading patterns
- Contributing drainage area's land use impacts (i.e., sediments)
- Foundation offsets
- Groundwater issues addressed
- Flat subgrade provided

Drainage area ratios (max. 2:1, traditional pavement-to-permeable pavement)

Paver field = 5,000 sq. ft.

Pavement drainage area = 7,500 sq. ft.




#### Underdrains & elbows












#### Observation wells



#### Edge restraints




#### Infiltration testing\*





<sup>\*</sup> Based on finished compaction

# Erosion & sediment control plan





# Maintain straight edging as much as possible

(pieces  $\geq 1/3$ rd the brick)







# Permeable Pavement Construction

Operation & Maintenance Workshop Session

#### Permeable Pavement - Construction

#### General

- Adhere to construction schedule
- Keep sediment away!
- Refer to applicable notes/details
- Construct during good weather
- Scarify subsoil (infiltrating practices)
- Use non-contaminated materials
- Plan revisions = O&M Plan revisions
- As-built drawings
- Milestone inspections

#### Permeable Pavement - Construction

Do not work on the subgrade when it is raining



Remove unintended sediments before backfilling






Operation & Maintenance Workshop Session

#### General

- All SCMs will require maintenance
- First year need \$ vs.
   long-term need \$



#### Bioretention Area Inspection and Maintenance Checklist

Facility:					
Location/Address	:				
Date:	Time:	Weather Conditions:		Date of Last Inspection:	
Inspector:			Title:		
Rain in Last 48 H	ours □ Yes □ No	If yes, list amoun	t and timing:		
Pretreatment: vegetated filter strip swale turf grass forebay other, specify:					□ none
Site Plan or As-B	uilt Plan Available:	□ Yes □ No			

Inspection Item		Comment	Action Needed
1. PRETREATMENT			
Sediment has accumulated.	□Yes □No □N/A		□Yes □No
Trash and debris have accumulated.	□Yes □No □N/A		□Yes □No
2. DEWATERING			
Standing water is present after 24 hours. If yes, describe sheen, color, or smell.	□Yes □No □N/A		□Yes □N
3. INLETS			
Inlets are in poor structural condition.	□Yes □No □N/A		□Yes □N
Sediment has accumulated and/or is blocking the inlets.	□Yes □No □N/A		□Yes □N
Erosion is occurring around the inlets.	□Yes □No □N/A		□Yes □N
3. VEGETATION			
Vegetation is wilting, discolored, or dying due to disease or stress.	□Yes □No □N/A		□Yes □N
Vegetation needs to be controlled through mowing or manual removal.	□Yes □No □N/A		□Yes □N
4. BIORETENTION MAIN INFILTRA	ITON AREA		
Trash and debris have accumulated.	□Yes □No □N/A		□Yes □N
Sediment has accumulated at the surface.	□Yes □No □N/A		□Yes □N
Topmost layer is caked or crusted over with sediment.	□Yes □No □N/A		□Yes □N
Erosion is evident.	□Yes □No □N/A		□Yes □N
Mulch is compacted.	□Yes □No □N/A		□Yes □N
Sinkholes or animal borrows are present.	□Yes □No □N/A		□Yes □N
5. SIDE SLOPES AND EMBANKMENT	Γ		
Erosion is evident.	□Yes □No □N/A		□Yes □N
Sinkholes or instability is evident.	□Yes □No □N/A		□Yes □N
6. OUTLETS AND OVERFLOW STRU	CTURE (i.e., catch basin)		•
Outlets or overflow structures in poor structural condition.	□Yes □No □N/A		□Yes □N
Sediment, trash or debris is blocking the outlets or overflow structure.	□Yes □No □N/A		□Yes □N
Erosion is occurring around the outlets or overflow structure.	□Yes □No □N/A		□Yes □N
Height from surface of practice to top of overflow structure is insufficient to allow for ponding during rain events.	□Yes □No □N/A		□Yes □N

dditional Notes			
et weather insp	 - V N-		

Site Sketch:

# Remove landscaping debris regularly



# Stockpile snow piles downslope



#### Do not apply any sealants





#### Vacuum/sweep 2X - 4X per year








#### **First-Year Maintenance**

- Remove accumulated sediments/debris from pretreatment devices
- Vacuum at least twice (early spring and late fall)
- Remove landscaping debris ASAP



## ANNUAL INSPECTIONS

Operation & Maintenance Workshop Session

## Annual Inspection - For all SCMs

Annual Inspection needs to be completed and submitted by June 1st


- Dry weather structural conditions
- Wet Weather function



## Annual Inspection - Form

Northeast Ohio Storm Water Training Council (NEOSWTC)

https://ohioswa.com/wpfd\_file/maintainingstormwater-control-measures-neoswtc-2017/



## Annual Inspection – Form

#### Bioretention Area Inspection and Maintenance Checklist

Facility:						
Location/Address:						
Date:	Time:	Weather Conditions:		Date of Last Inspection:		
Inspector:			Title:			
Rain in Last 48 Hours   Yes   No   If yes, list amount and timing:						
Pretreatment: vegetated filter strip swale turf grass forebay other, specify:						
Site Plan or As-Bu	ilt Plan Available:	□ Yes □ No				

Inspection Item		Comment	Action Needed
1. PRETREATMENT			
Sediment has accumulated.	□Yes □No □N/A		□Yes □No
Trash and debris have accumulated.	□Yes □No □N/A		□Yes □No
2. DEWATERING			
Standing water is present after 24 hours. If yes, describe sheen, color, or smell. 3. INLETS	□Yes □No □N/A		□Yes □No
			1
Inlets are in poor structural condition.	□Yes □No □N/A		□Yes □No
Sediment has accumulated and/or is blocking the inlets.	□Yes □No □N/A		□Yes □No
Erosion is occurring around the inlets.	□Yes □No □N/A		□Yes □No
3. VEGETATION			
Vegetation is wilting, discolored, or dying due to disease or stress.	□Yes □No □N/A		□Yes □No
Vegetation needs to be controlled through mowing or manual removal.	□Yes □No □N/A		□Yes □No
4. BIORETENTION MAIN INFILTRA	TION AREA		
Trash and debris have accumulated.	□Yes □No □N/A		□Yes □No
Sediment has accumulated at the surface.	□Yes □No □N/A		□Yes □No
Topmost layer is caked or crusted over with sediment.	□Yes □No □N/A		□Yes □No
Erosion is evident.	□Yes □No □N/A		□Yes □No
Mulch is compacted.	□Yes □No □N/A		□Yes □No
Sinkholes or animal borrows are present.	□Yes □No □N/A		□Yes □No
5. SIDE SLOPES AND EMBANKMEN	Γ		
Erosion is evident.	□Yes □No □N/A		□Yes □No
Sinkholes or instability is evident.	□Yes □No □N/A		□Yes □No
6. OUTLETS AND OVERFLOW STRU	CTURE (i.e., catch basin)		
Outlets or overflow structures in poor structural condition.	□Yes □No □N/A		□Yes □No
Sediment, trash or debris is blocking the outlets or overflow structure.	□Yes □No □N/A		□Yes □No
Erosion is occurring around the outlets or overflow structure.	□Yes □No □N/A		□Yes □No
Height from surface of practice to top of overflow structure is insufficient to allow for ponding during rain events.	□Yes □No □N/A		□Yes □No

Additional Notes		
Wet weather inspection needed	□ Yes □ No	

Site Sketch:





#### Bioretention Cell Maintenance









## ALL ABOUT THE SIGNAGE

Operation & Maintenance Workshop Session



### **Minimum Suggested Specs**

- 3 feet (36") above ground height
- 2'x3' (24"x36)" panel dimensions
- Highly encourage each project to take their own unique approach and design a customize sign but will provide a template.



### **The Sewer District responsibility**


- Permanent educational signage is required and must be approved
- Providing minimum criteria regarding signage
- Logo on any public advertisement or outreach efforts related to the GI project.
- The Sewer District shall be permitted and have the right to photograph any project that has been selected for funding, to use for public outreach and education projects.

### **Awarded applicant responsibility**

- Permanent educational signage is required and must be approved.
- Design life expectancy of the project
- Initial cost of one permanent signage is an eligible expense.
- Installation within 30 days of completion of the GI Grant awarded project.
- Once constructed, the Grantee shall coordinate the Project's educational signage content and placement with the District.
- Signage standard language
  - "The purpose of the project is to remove stormwater from the combined sewer system..."
  - The Sewer District shall be acknowledged on any public advertisement or outreach efforts related to the GI project. This project was funded by The Northeast Ohio Regional Sewer District (DRAFT) Branding is below

## Educational Co-Benefits Signage Too Small






# Educational Co-Benefits Signage Maintenance













### **MENLO PARK ACADEMY NATURE LAB**

How stormwater management at our school works to protect Lake Erie

### WHAT IS GREEN INFRASTRUCTURE?

Stormwater runoff is a major source of water pollution in urban areas. Historically, cities have used infrastructure like pipes and gutters to collect stormwater runoff and move it to treatment facilities through combined pipes (pipes that carry both sewage and rainwater). Sometimes, rainstorms produce more runoff than the pipes can hold. So what happens next?! The overflow, a combination of untreated stormwater and sewage from the "combined" pipes, is released directly into Lake Erie! Yikes!

Green Infrastructure is a different approach to stormwater management that collects, absorbs, and filters stormwater where it falls. Green Infrastructure can be natural or man-made and includes elements such as wetlands, cistems, soils, permeable pavement, infiltration basins, and more. These elements mimic, protect, and restore the natural water cycle. They are designed to allow rainwater to percolate through the soil, reducing the amount of runoff in the sewer system, which in turn reduces overflows and pollution.






### GREEN INFRASTRUCTURE AT MENLO PARK: THE NATURE LAB!

The Nature Lab, generously funded through the Northeast Ohio Regional Sewer District's Green Infrastructure Grant Program, will be used to foster hands-on connections between learning and nature. A bioretention cell collects surface runoff and facilitates stormwater percolation into and through the soils below our feet, and 100% of the rainwater runoff from the school's rooftop is diverted into underground chambers for infiltration.

As stormwater slowly moves through the soil (instead of into pipes), our school is helping to restore the natural hydrologic functions of our regional watershed. By keeping Menlo Park's stormwater out of the combined sewer system, we are helping reduce the risk of overflows and pollution within our community!



### **MENLO PARK ACADEMY NATURE LAB**

How stormwater management at our school works to protect Lake Erie

### WHAT IS GREEN INFRASTRUCTURE?

Stormwater runoff is a major source of water pollution in urban areas. Historically, cities have used infrastructure like pipes and gutters to collect stormwater runoff and move it to treatment facilities through combined pipes (pipes that carry both sewage and rainwater). Sometimes, rainstorms produce more runoff than the pipes can hold. So what happens next?! The overflow, a combination of untreated stormwater and sewage from the "combined" pipes, is released directly into Lake Erie! Yikes!


Green Infrastructure is a different approach to stormwater management that collects, absorbs, and filters stormwater where it falls. Green Infrastructure can be natural or man-made and includes elements such as wetlands, cistems, soils, permeable pavement, infiltration basins, and more. These elements mimic, protect, and restore the natural water cycle. They are designed to allow rainwater to percolate through the soil, reducing the amount of runoff in the sewer system, which in turn reduces overflows and pollution.



#### GREEN INFRASTRUCTURE AT MENLO PARK: THE NATURE LAB!

The Nature Lab, generously funded through the Northeast Ohio Regional Sewer District's Green Infrastructure Grant Program, will be used to foster hands-on connections between learning and nature. A bioretention cell collects surface runoff and facilitates stormwater percolation into and through the soils below our feet, and 100% of the rainwater runoff from the school's rooftop is diverted into underground chambers for infiltration.

As stormwater slowly moves through the soil (instead of into pipes), our school is helping to restore the natural hydrologic functions of our regional watershed. By keeping Menlo Park's stormwater out of the combined sewer system, we are helping reduce the risk of overflows and pollution within our community!



## Educational Co-Benefits Signage Single Post




## Educational Co-Benefits Signage Single Post
















# Educational Co-Benefits Signage Wall Mount



# Educational Co-Benefits Signage Wall Mount





# Educational Co-Benefits Signage Location





#### **OPTION 1**

GI Grant Program
Reimbursement Request

#### **OPTION 2**

GI Grant Program
Progress Report Only

#### **OPTION 3**

GI Grant Program
Request for Project Extension

# DOCUMENT SUBMITTAL PROCESS

Operation & Maintenance Workshop Session

### **Awarded Project Partners Resource Forms**

Signage Guideline

<u>Instructions on How to Fill out the Online GI Grant Reports and Requests</u>

<u>Plan Review - Drawing Submittal Portal SagesGOV</u>

#### To proceed with your required documentation request and reporting, follow these steps:

- 1. Choose one of the following three options below.
- 2. Refer to the instructions provided above to properly fill out and submit your chosen form below.

### **GI Grant Awarded Project Partners Required Documentation Portals**

Below are instructions to submit a Reimbursement Request, Quarterly Progress Report, and a Project Extension Request. Please choose from the following three options:

#### **OPTION 1**


Click Here to Submit GIG Reimbursement Request

#### **OPTION 2**

Click Here to Submit GIG Quarterly Progress Report

#### **OPTION 3**

Click Here to Submit GIG Project Extension Request



# CONCLUSION

Operation & Maintenance Workshop Session

## Conclusion

## **Maintenance Consideration**







## Conclusion

### **Stormwater Fee Credits**

- Provide Appendix A only
- GIG Program Agreement requires annual inspection by June 1st
- Credit renewal requires annual inspection
- Credit approval date will align with GIG inspection requirement

## Questions?

Jessica S. Cotton, GISP, GIP Grant Programs Administrator (GI Grant Point of Contact) 216.881.6600 x6458 CottonJ@neorsd.org





Derek Vogel, P.E.
Project Manager Stormwater Design & Construction
VogelD@neorsd.org

Keith McClintock Manager of Watershed Programs McClintockK@neorsd.org

